## EDCON SIELS SLAM CATCH INSTALLATION GUIDE

Before installing your Slam Catch please ensure you read and follow this simple guide to assist you to ensure smooth & trouble free operation.



Please follow all manufacturer safety instructions and recommendations for any hazardous tasks such as grinding and welding.

Page 1 of 4

#### Sydney Metro

Blacktown Brookvale Revesby

Rural

Bathurst Orange 15 Garling Road Kings Park 10/9-13 Winbourne Road Brookvale 122 Milperra Road Revesby

51 Sydney Road Raglan 23 Leewood Drive Orange

# EDCON SIELS SLAM CATCH INSTALLATION GUIDE

**Step 1** Weld or screw your hinges onto the gate and hang the gate onto the post.

**Step 2** Tack weld the striker plate to the frame in the desired location.



#### Sydney Metro

Blacktown Brookvale Revesby

Rural

Bathurst Orange 15 Garling Road Kings Park 10/9-13 Winbourne Road Brookvale 122 Milperra Road Revesby

51 Sydney Road Raglan 23 Leewood Drive Orange Page 2 of 4

# EDCON SIEED SLAM CATCH INSTALLATION GUIDE

**Step 3** Place the spring loaded latch onto the gate and ensure the pin is in the centre of the stiker plate.

**Step 4** Ensure the pin contacts the edge of the angled section of the striker plate and tack weld the latch in place.





Incorrect latch location The pin must not over lap or pass the lip of the striker plate

Correct latch location The pin is in contact with the angled section of the striker plate

Page 3 of 4

#### Sydney Metro

Blacktown Brookvale Revesby

Rural

Bathurst Orange 15 Garling Road Kings Park 10/9-13 Winbourne Road Brookvale 122 Milperra Road Revesby

51 Sydney Road Raglan 23 Leewood Drive Orange

# EDCON SIELS SLAM CATCH INSTALLATION GUIDE

**Step 5** Weld the cam to the latch body in the location indicated by the red arrow. A decent tack weld will suffice.

**Step 6** Test the gate opens and closes freely and the pin doesn't fowl on or inside the striker plate.

**Step 7** Once satisfied that both the plate and latch are in the correct location, fully weld the plate and latch in place.



*Quick Tip - Use a spray lubricant such as WD-40 regularly to ensure the pin moves freely and allows the gate to open and close with ease.* 

Page 4 of 4

#### Sydney Metro

Blacktown Brookvale Revesby

Rural

Bathurst Orange 15 Garling Road Kings Park 10/9-13 Winbourne Road Brookvale 122 Milperra Road Revesby

51 Sydney Road Raglan 23 Leewood Drive Orange